LAMP

HES INSTALLATION MANUAL

FOR HES3D-120-A100 CONCEALED HINGE


Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

ABOUT THE PRODUCT

- This product is a concealed hinge for indoor use to be recessed in the cut out on door and doorframe.
- 3 way adjustment function allows vertical, horizontal, and depth adjustment.

DOOR SPECIFICATION

Min. Door thickness	29 mm	
Max. Door weight	30kg per 2 hinges, 40kg per 3 hinges	
Max. Door size	Width: 900 mm, Height: 2400 mm	



COMPONENT PARTS (PER BOX)

· Concealed hinge	2 pcs
· Screw cover	4 pcs x 2 bags
·Template	1 pc
\cdot Countersunk head tapping screw 5x20	4 pcs x 2 bags
· Hex Key 3 mm	1 pc

FOR YOUR SAFE WORK AND CORRECT INSTALLATION

Meaning of symbols

Warning Prohibited Require


Caution: If these cautions are not followed, it may result in injury or damage.

- 1 It is necessary to manufacture the frame with sufficient strength so that it endures the weight of the door and any impact upon opening/closing the door. Only use designated screws and ensure that they are fastened firmly. A frame with poor strength or loose screws might result in the door falling and causing injury.
- O Do not try to use this product for anything other than its original purpose. Do not use any part for applications outside of its specification.
- Q Use in conjunction with a door closer is not recommended. For soft-close option, we recommend Sugatsune LDD-V or LDD-S door damper.
- Make sure to follow the designated dimensions, specifications, and horizontal/vertical angles. Make sure that the frame is not warped, since it may affect the movement of the door.
- 1 This product is a part for architectural fittings. After installation, make sure to test the finished product thoroughly to ensure that it is well-functioning and safe. Please inform the end user about general precautions and safety to prevent improper use.
- Make sure to check the screws for slack at regular intervals (one month from first usage, half a year, and then one time every year is recommended).
- 1 Be sure to use a door stopper which restrict the opening angle within 100°. If not, the hinge may be broken and the door

INSTALLATION DRAWING (EXAMPLE) CUT OUT DRAWING FOR DOOR AND DOORFRAME Round edges of door and frame by applying cuts with "C1 and over" or "R1 and over (Reference to "%" in the drawing.) 21 Max Reference surface 23 6.5 of doorframe Reference surface 5 mm of doorframe Max Reference surface of door Door frame Door 8×R6 8×R6 Door Door Reference with a door stopper. Reference Reference surface surface of doo surface of door

INSTALLATION PROCEDURE


1 Installing Base frame to Cabinet



2 Installing Hinge to Door 3 Hanging Door Countersunk head tapping screw 5 x 20

> While holding the door, insert Hinge main body into the Base frame on Doorframe, Keep holding the door and fix the hinge with the fixing screws at once.

ADJUSTING DOOR POSITION



Vertical, depth adjustment

coupling it with Hinge main body.

Loosen the screws 180° -360°, then hold the door at the suitable position and re-tighten the screws. Use wedges to support the door. (Tightening torque is 3.5 N·m.)

Vertical adjustment

screw

igwedge Do not remove depth adjustment screw. The door may be dropped.


Horizontal adiustment -

Turn the two screws to move the door to the left or right. (Turn the screws clockwise to move the door to the left.)

- Turn both screws little by little, same amount. The hinge may be broken if you keep turning one screw only.
- \bigwedge Horizontal adjustment range is \pm 2 mm. When turning the screw to the right, if you move the part more than 2 mm, the cover cannot be put on, since the part protrudes. If you still turn the screw, the door will be dropped.

INSTALLING DOOR STOPPER

MOUNTING SCREW COVERS



SUGATSUNE KOGYO CO.,LTD Tokyo, JAPAN

Phone: +81 (0)3 3866 2260 E-mail:export@sugatsune.co.jp Phone: +86 21 3632 1858

SUGATSUNE KOGYO (UK) LTD

SUGATSUNE EUROPE GmbH Phone: +49 211 53812900 E-mail:sales@sugatsune.eu

ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.

Guangzhou, CHINA E-mail:lamp@sugatsune.com.cn

SUGATSUNE KOGYO INDIA PRIVATE LIMITED SUGATSUNE CANADA, INC.

E-mail:lamp@sugatsune.com.cn

SUGATSUNE SHANGHAI Co., LTD

SUGATSUNE AMERICA, INC

Phone: +1 310 329 6373 E-mail:sales@sugatsune.com

Chicago, USA

Phone: +1 312 461 1081 E-mail:chicagoshowroom@sugatsune.com

Phone: +1 514 312 5267 E-mail:support@sugatsune.ca