
# LAMP. GS-GH20 Glass Pivot Hinge, GS-GB20 Glass Bracket Installation Manual

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.


## **ABOUT THE PRODUCT**

- Pivot hinge for glass show case
- Door can be mounted with assembled hinges.
- Horizontal door position is adjustable at mounted status.
- Vertical door position can be adjusted by adding a washer or a spacer.
- Hinges, brackets and locks with same design concept.



#### **SPECIFICATIONS**

Door size	W700 × H1600
Door weight	Max. 20 kg
Glass thickness	6、8 mm (Door)
	8、10 mm (Top glass)



## FOR YOUR SAFE WORK AND CORRECT INSTALLATION

#### Meaning of symbols





## **!** Caution If these cautions are not followed, it may result in injury or damage.


- Apply door stoppers to protect the hinges and glass door when closing.
- Prepare a cabinet which endures the weight of the door.
- ① Use a tempered glass. It is recommended to use shatter-proof film on the glass. For areas where the glass brackets grip, make sure to remove the shatter-proof film before installing.




### **INSTALLATION DRAWING (EXAMPLE)**

Right Opening Shown. A left opening door is the mirror opposite except with hinge A and B reversed on the left side.

#### [1] Wood Cabinet






### DOOR AND CABINET PROCESS DIMENSIONS


(Right opening Shown. The left opening is a mirror image.)

#### Wood top board and Wood bottom board


<sup>2</sup> Use hardwood or reinforce this part with adhesive to prevent the insert nut from loosening.




#### Glass door for wood top board



#### Glass top board (for GS-GB20)



#### Glass door for glass top board







## **COMPONENT PARTS (PER BOX)**


INSTALLATION Hinge GS-GH20 (Right opening)

Hinge GS-GH20 Right opening shown. A left opening door is the mirror opposite except with hinge A and B reversed on the left side.




**Bracket GS-GB20(Right opening)** 






Provided screw:

Countersunk head tapping screw 3.5 x 15...4 pcs



To increase the bottom gap of the door.




o increase the bottom


gap of the door.

4 Back cover installation


Below figure shows opened status.




## 5 Door adjustment (±3 mm)










For doors with a cam lock,, check the movement of the deadbolt or cam when adjusting door position.


## INSTALLATION Bracket GS-GB20


## 1 Assembling bracket parts

## 2 Disassembling top pivot

## 3 Assembling bush







#### Door mount (See page3 13, to page4 15.)

SUGATSUNE KOGYO (UK) LTD

SUGATSUNE EUROPE GmbH

ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.

E-mail:lamp@sugatsune.com.cn

Guangzhou, CHINA

Phone: +86 20 6639 3552 E-mail:lamp@sugatsune.com.cn

# SUGATSUNE KOGYO INDIA PRIVATE LIMITED Mumbai, INDIA Phone: +91 22 28314490/91 E-mail:sales@sugatsune.in

### SUGATSUNE CANADA, INC.

Chicago, USA

SUGATSUNE AMERICA, INC

Phone: +1 312 461 1081 E-mail:chicagoshowroom@sugatsune.com.

Phone: +1 514 312 5267 E-mail:support@sugatsune.ca