

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.


SPECIFICATIONS

Item Name	Shaft A ※1	Shaft B ※1
HG-TMH1530	1.5±20% N·m	3.0±20% N·m
HG-TMH2030	2.0±20% N·m	


※1 Refer to the right drawings to identify the shafts.

Items to be prepared:

- Countersunk head screws M4 or
- Countersunk head tapping screws.





[Markings of item name]





CUT OUT DIMENSIONS





- **Fixed panel and Flap** (Both dimensions are the same.)




Thickness = 20



Thickness ≥ 20




[Motion of assembled board]



- ❗ **Be sure to use the boards and screws which bears the operating force.**

INSTALLATION PROCEDURE


- **Mounting hinges**



- ❗ Fasten the hinges firmly so as not to be dropped.
- ❗ Align the axis of the hinges.

Caution

Direction of the hinges need to be the same.



※2 Both hinges mounted upside down is applicable.

SUGATSUNE KOGYO CO.,LTD
 Tokyo, JAPAN
 Phone: +61 (0)3 3866 2260 E-mail: export@sugatsune.co.jp

SUGATSUNE KOGYO (UK) LTD
 Reading, UK
 Phone: +44 118 9272 955 E-mail:sales@sugatsune.co.uk

SUGATSUNE EUROPE GmbH
 Düsseldorf, GERMANY
 Phone: +49 211 53812900 E-mail:sales@sugatsune.eu

SUGATSUNE SHANGHAI Co., LTD
 Shanghai, CHINA
 Phone: +86 21 3632 1858 E-mail:lamp@sugatsune.com.cn

Guangzhou, CHINA
 Phone: +86 20 6639 3552 E-mail:lamp@sugatsune.com.cn

SUGATSUNE KOGYO INDIA PRIVATE LIMITED
 Mumbai, INDIA
 Phone: +91 22 26314490/91 E-mail:sales@sugatsune.in

SUGATSUNE AMERICA, INC
 California, USA
 Phone: +1 310 329 6373 E-mail:sales@sugatsune.com

Chicago, USA
 Phone: +1 312 461 1081 E-mail:chicagoshowroom@sugatsune.com.

SUGATSUNE CANADA, INC.
 Phone: +1 514 312 5267 E-mail:support@sugatsune.ca